NOTES:

We have found that on most machines, the passenger tire is leaning in at top (negative camber). The passenger side should be pretty close to 0 degrees camber with only 1 thick shim on wheel side. The driver side should be pretty close to 0 degrees camber with 3 thick shims to wheel side

